# Communicator 5 Accessible Apps - Accessible YouTube: Quick Guide

This document provides instructions on how to use the Accessible YouTube App to stream video content and enjoy all YouTube capabilities.

Requirements: Users do not need a YouTube / Google account to use Accessible YouTube. However, users can login with their Google account to browse viewing history, receive personalized recommendations, and sync with other devices. In addition, an unlocked device with access to the Internet is also required.

Note: Refer to the **Getting Started with Communicator 5 Accessible Apps Quick Guide** for instructions on how to set up Communicator 5 Home Page with the accessible apps collection.

Launch Accessible YouTube

Launch Communicator 5

On Communicator 5 Home Page, select Accessible YouTube to launch

Accessible YouTube home control toolbar appears on the left

Open YouTube Home Page

- If logged in previously, open personalized YouTube Home Page
- If the user has a Google account and wants to login, use the **Login and Info** button below to log in

Log into YouTube for first-time Accessible YouTube user or previously logged out account
*Refer to the **Accessible YouTube Login** section below for details*

Return to the Communicator 5 Home Page

Accessible YouTube Login

After selecting **Login and Info** on the home control toolbar, the left toolbar provides buttons for logging in, logging out, and more. **Note:** Login is optional for a personalized YouTube experience.

Open the main control toolbar (left) and YouTube Home Page (right)

Open Accessible YouTube online training cards

Open Google Account page

Log out from Google / YouTube

Return to the Communicator 5 Home Page

- **Saved Account** – allow user to select an existing account on the right
- **New Account** – use another account and follow the prompts on screen to log in

Navigate and Watch the YouTube Videos

After launching Accessible YouTube, the control toolbar provides buttons for all the capabilities of YouTube in an easy and more accessible way.

Main Control Toolbar

Provide additional control options
*Refer to **Menu Toolbar** below for details*

Open the **Select Video** page

Reload the video grid screen

- All videos are dwell enabled and ready for selection
- Select and open a specific video
- **Pause Dwell** – disable dwell on videos to allow more time for browsing; return to main control toolbar
- **Go to Video Page** – switch the opened video to full-screen mode and open **Video Page Toolbar** (*see below for details*)

Menu Toolbar

Go to YouTube Home Page

Open Communicator 5 keyboard for typing keywords to search for videos

Recover YouTube, close extra windows and more
(*Refer to **Communicator 5 Accessible Apps - Utilities and Options Quick Guide** for details*)

Return to the previous toolbar

Open a list to select a view of the content organized by History, Subscription Feed, Watch Later, Liked Videos or Trending Videos

Show the list of channels the user has subscribed to and select one if desired

Adjust speaker volume, skip ads, and more
(*Refer to **Communicator 5 Accessible Apps - Utilities and Options Quick Guide** for details*)

Exit the app and return to Communicator 5 Home Page

Video Page Toolbar

Switch to the Menu toolbar

Return to the previous toolbar

Mute the current video

Switch to volume control toolbar to mute, adjust volume up or down

Play or pause the current video

Switch to a toolbar with options for forwarding and rewinding the current video, such as 5 seconds, 60 seconds, start over, bookmarks, etc.

Skip ads or pop-ups (only when YouTube allows it)

Like or Dislike the video, Subscribe or Unsubscribe to the current channel, add to your Watch Later list, or view the current channel

Provide options to toggle subtitles/ CC, or toggle autoplay

Show a table with other videos on the playlist that the current video is in. The current video continues playing on the background.

(**This button appears only if the current video is part of a playlist.)

Show the related videos determined by YouTube. The current video continues playing on the background.

The toolbar changes to the main control toolbar for browsing and selecting another video. Use the **Back** button to return to the current video.

Toolbar buttons: Menu | Back | Mute | Player Volume | Play/Pause | Forward and Rewind | Skip Ad | More | Video Options | Playlist | Related Videos