



Windows 10 Apps in Tobii Dynavox Communicator 5

Adding Windows 10 Apps to Tobii Dynavox Communicator 5

To be able to launch Windows 10 Apps in Tobii Dynavox Communicator 5, follow these steps:



1. Go to the Windows Desktop
2. Browse for the App from the **Windows Start Menu**.
3. Select and hold the App.
4. Drag the App to the Desktop of the device.
5. Drop the App onto the Desktop.
A shortcut to the App have been created on the Desktop.
6. Go back to Communicator 5.
7. Open the Quick Menu


8. Select  (Edit Home Page) button.

9. Select the  (Add Page Sets) button.

10. Select the **Other Files & Applications** option.

11. Select the **Desktop** tab on the left hand side.

12. Browse for the Shortcut you just created using the  and  buttons.



13. Select the Shortcut.

14. Select the  to add the Windows 10 App to the Home Page.

Support for Your Tobii Dynavox Device

Get Help Online

See the product-specific Support page for your Tobii Dynavox device. It contains up-to-date information about issues and tips & tricks related to the product. Find our Support pages online at: www.TobiiDynavox.com or www.myTobiiDynavox.com.

Contact Your Sales Representative or Reseller

For questions or problems with your product, contact your Tobii Dynavox sales representative or authorized reseller for assistance. They are most familiar with your personal setup and can best help you with tips and product training. For contact details, visit www.TobiiDynavox.com/contact