To Insert Cards

Make sure the Barcode is face up under the frame.

To Record Audio

Press and hold the Mode button, press the Record button, release Mode, then release Record. Press/hold a key, speak close to the mic!


Press   Press   Release Release

Press Mode button to Exit Record Mode

To Apply Keyguards

Insert long edge first, then push down. Clicks into place.

To Record IR

First, same procedure as recording Audio. Then, press and release the Record button a second time. Press/release a key, record!

Press   Release

To Enter and Exit Setup Mode

With no Card in place, hold the Mode button and press the green arrow to enter. Press the red arrow to exit.

To Change Speaker Volume

In Setup Mode, + for more, - for less. With a Card in place, hold Mode button at the same time.

▭ Mode button

Setup Mode

For changes within Setup Mode, see: **Tobii S32 User's Manual>Setup Menu>Tobii S32 Scan**.

S32 Support

Contact your local dealer or visit: www.tobii.com.

Important LEDs

○ ○ ● - Playing Audio
● ○ ● - Executing IR
○ ● ○ - With sound: Error or Locked
○ ● ● - Red Flashing: Waiting to record audio
● ● ○ - Flashing: Waiting to record IR
● ○ ○ - Data Transfer
○ ● ○ - Change Batteries