Communicator 5 Accessible Apps - Accessible Kindle: Quick Guide

This document provides instructions on how to use Accessible Kindle to read books.

Requirements: To use Accessible Kindle, an (Amazon) Kindle account is required. If a user has not logged in with Accessible Kindle previously, make sure to have the login credentials available. An unlocked device with access to the Internet is also required.

Note: Refer to the **Getting Started with Communicator 5 Accessible Apps Quick Guide** for instructions on how to set up the Communicator 5 Home Page with the accessible apps collection.

Launch Accessible Kindle



© 2020 Tobii Dynavox. All Rights Reserved.

Accessible Kindle Login

After selecting **Login and Info** on the home control toolbar, the left toolbar provides buttons for signing in, signing out and more.



- **Email or Phone** and **Password** – bring up Communicator 5 keyboard to enter information
- **Keep Me Signed In** - checks the “Keep me signed in” box on the main screen
- **Sign In**

Browse Library

After launching Accessible Kindle and signing in, the Library view loads automatically. The library toolbar provides buttons for browsing the user’s Kindle library books in an easy and more accessible way.



© 2020 Tobii Dynavox. All Rights Reserved.

Library Toolbar



Menu Toolbar



© 2020 Tobii Dynavox. All Rights Reserved.

Reader Toolbar



© 2020 Tobii Dynavox. All Rights Reserved.